

Downloading and installing the model 02 drivers for a generic Windows XP or Windows Vista install

Downloading the drivers

ONLY USE OQO APPROVED DRIVERS! Failure to use drivers obtained at OQO's download site may adversely affect system functionality and stability.

The latest version of the drivers may be downloaded from OQO's website:
<http://www.oqo.com/support/downloads.html>

Learning more about package contents

A description of the package contents, any prerequisites, and installation instructions may be found in the README file included with each driver package.

Installation order

The drivers should be installed in the following order; you must restart your computer after every driver install.

1. S3 Display Driver
2. VIA System Drivers
3. Sigmatel Audio Driver
4. Wacom Pen Tablet Driver
5. Toshiba BT Stack
6. OQO Manager
7. For model 02 owners with the optional EVDO WWAN modem installed (Sprint or Verizon), please follow the instructions below. After installing OQO Manager and restarting, you will see the following message:
"A WWAN modem has been detected, however no drivers are installed. Please install your carrier drivers which can be found at <http://www.oqo.com/support>. Afterwards, please re-run DETECTWWAN.EXE located in C:\Program Files\OQO\OQOManager."
 - a. Install the following packages
 - i. Novatel Mobile Broadband Driver package
 - ii. Sprint PCS Connection Manager or Verizon VZAccess Manager
 - b. Run DETECTWWAN.EXE and then restart the computer
 - This is normally located in: C:\Program Files\OQO\OQOManager
 - You will know you have successfully run DETECTWWAN.EXE when the WWAN entry shows up in your OQO Wireless Dashboard after restarting.
If the WWAN entry is not available in the OQO Wireless Dashboard, please run DETECTWWAN.EXE again and then restart the computer.